



O-PRT-00005-OFC_C_R

INSTALLATION INSTRUCTIONS -
NOTICE D'INSTALLATION -
NOTICIA DE INSTALACIÓN -
INSTALLATIONSHINWEISE -
ISTRUZIONI PER L'INSTALLAZIONE
- INSTRUCCOES DE INSTALACAO -
MONTÁZNÍ NÁVOD -
РУКОВОДСТВО ПО МОНТАЖУ -




29, Bd Edgar Quinet 75014 Paris France
www.obsta.com


Technical Data

Designation	OFC - RI - SOL - G		P/N																								
	- : no option	G : with GPS																									
Input voltage	10-36 Vdc		• • •																								
Connexion	By terminal connexion : 6mm ² max for power supply, 1.5mm ² max for control		all																								
Optional interface	Built-in photosensor → see (A)		•																								
	Built-in GPS → see (B)		•																								
Attachment	By 4 M8 screws		all																								
Setting of dip switches	<table border="1" style="width: 100%;"> <thead> <tr> <th>Switch #</th> <th>Default value</th> <th>Function</th> <th>Comment</th> </tr> <tr> <th></th> <th>ON</th> <th>OFF</th> <th></th> </tr> </thead> <tbody> <tr> <td>1</td> <td>X</td> <td>Normal / Reset</td> <td>Switch to reset the light (to be used only for maintenance)</td> </tr> <tr> <td>2</td> <td>X</td> <td>Master / Slave</td> <td>Master mode (default mode)</td> </tr> <tr> <td>3-4</td> <td>X</td> <td>Test switches</td> <td>always OFF</td> </tr> <tr> <td>5-12</td> <td>-</td> <td>Factory setting of the light</td> <td>See below</td> </tr> </tbody> </table>			Switch #	Default value	Function	Comment		ON	OFF		1	X	Normal / Reset	Switch to reset the light (to be used only for maintenance)	2	X	Master / Slave	Master mode (default mode)	3-4	X	Test switches	always OFF	5-12	-	Factory setting of the light	See below
Switch #	Default value	Function	Comment																								
	ON	OFF																									
1	X	Normal / Reset	Switch to reset the light (to be used only for maintenance)																								
2	X	Master / Slave	Master mode (default mode)																								
3-4	X	Test switches	always OFF																								
5-12	-	Factory setting of the light	See below																								

Obstaflash compact OFC




Wiring of power supply



A Option with R

Photosensor to be oriented in the North when the light is located in the North hemisphere



B Option with G

+ GPS antenna with magnet to be fixed outside and unmasked



Main configurations

Configuration number	Positions of the dipswitches (5-6-7-8-9-10-11-12)	Interface required	operation	type
1	10000000	(R)	night only operation	medium intensity type B [minimum ICAO requirement at 20 flashes per minute]
2	01000000	-		
3	11000000	(G)	flash synchronisation through the GPS	medium intensity type C [fixed mode]
4	00100000	-		

* Warning : Changing the configuration may change significantly the power consumption of the light and the size of the solar kit

